

Important: Read all instructions prior to installation.


RGB Amplifier

Safety and Notes

- This controller requires a 12–24 VDC power supply.
- Do not exceed max load of 24 amps.
- Inteded for indoor use only.
- Observe proper polarity when connecting wiring.
- To reduce risk of electric shock, ensure power supply is off before performing any installation or wiring procedures.
- Make sure to match input/output channels when wiring.

Specifications

RGBW-A6	
Input Voltage Range	12–24 VDC
Max Amps per Channel	6 Amps/CH
Operating Temperature	-20~60°C (-4~140 °F)



Wiring Diagram

